Welcome to iPar! Your cart has been equipped with the new *iPar7B* - *Battery Powered Golf GPS System*. In addition to providing accurate, easy to read hole information, the iPar7B interfaces with the clubhouse to update course changes, like pin zones, as well as receive messages from the golf staff and inclement weather warnings. The lithium ion battery provides 4-5 rounds of power depending on use. After 10 minutes without use, iPar7B will "*Sleep*" until it moves or is pressed to conserve power. To deactivate GPS and clubhouse communication, simply turn the unit *OFF*.

## Instructions:

- Charge before use
- Plug iPar charger into wall socket
- Connect charging cable to iPar7B
  \*\*iPar must be OFF when Charging\*\*
- Battery Charger Indicator Light. RED-Charging / GREEN-Fully Charged
- Approximately twenty to twenty five (20-25) hours of operation per charge
- Activate/Deactivate by using the red *Power Switch* at the top left corner of the iPar7B (-)ON / (0)OFF
- Signal generally locks within (2) minutes
  \*iPar must be outdoors to obtain signal.
- "*Proceed to tee…*" message appears when iPar7B is connected and ready to play
- Yardage and hole information update automatically and continuously; allowing iPar to operate "hands free" while navigating the course



Charging Port is located on the back of the iPar7B. Turn the red power switch OFF(0) when charging. Green light on iPar charger indicates when battery is completely charged. To maximize battery strength...*turn it ON* when you leave the house, turn it OFF when you leave the course.





iPar7B alerts when it enters a restricted area, such as Cart Path Only or Green Aprons, and stops when it exits the area.